

*Digital Surround Processor  
AV Control Stereo Receiver*

**SF-DX7**

**Operating Instructions**



Remote control included.



**Technics<sup>®</sup>**

Before connecting, operating or adjusting this product,  
please read these instructions completely.  
Please keep this manual for future reference.

## Dear Customer

Thank you for purchasing this system.  
For optimum performance and safety, please read these instructions carefully.

Front cover of the receiver is open in all explanations in these operating instructions.

The model number and serial number of this product can be found on either the back or the bottom of the unit.  
Please note them in the space provided below and keep for future reference.

	MODEL NUMBER	SERIAL NUMBER
Processor:	SH-AC500D	
Receiver:	SA-AX7	

User memo:

DATE OF PURCHASE \_\_\_\_\_  
DEALER NAME \_\_\_\_\_  
DEALER ADDRESS \_\_\_\_\_  
TELEPHONE NUMBER \_\_\_\_\_

### Enjoying DVD and other digital sources

This system provides you with the opportunity to enjoy the high quality surround effects found on DVDs and other digital sources. Before you playback these sources, though, you need to prepare this system.

Follow these steps to get the most out of your system.


1. **Connect the processor and receiver; page 8.**
2. **Connect the DVD player (or other digital equipment); page 9.**
3. **Connect your speakers; pages 14, 15, and 16.**
4. **Do the speaker settings on the processor; pages 28 to 31.**

The system is now ready for playback.

Follow the steps on pages 32 and 33, and sit back and enjoy the powerful sounds on your system.

### CAUTION

Do not place a tape deck, CD, or DVD player on top of the receiver.  
Heat radiated from the top of this unit may cause damage to the software.



**NO**

## Table of contents



Precautions .....	4
Surround guide .....	5
Front panel controls .....	6
Equipment connections .....	8
Antenna connections .....	12
Speaker connections .....	14
Concerning the remote control .....	17
<b>Basic operations .....</b>	<b>18</b>
To enjoy bi-amp sound .....	20
To adjust the tone quality .....	20
To adjust the sound balance .....	20
To adjust the subwoofer level .....	21
To compensate when the volume is low .....	21
To adjust the output range of the subwoofer .....	21
<b>Listening to radio broadcasts .....</b>	<b>22</b>
Sequential tuning .....	22
Direct tuning .....	23
Preset tuning .....	24
<b>Reproduction modes .....</b>	<b>26</b>
On the processor .....	26
On the receiver .....	27
<b>Preparation for DVD playback .....</b>	<b>28</b>
Speaker settings for the processor .....	28
Adjusting speaker output level .....	29
Adjusting the delay time .....	31
<b>Enjoying DVD .....</b>	<b>32</b>
<b>Preparing for Dolby Pro Logic on the receiver .....</b>	<b>34</b>
Setting the center mode and adjusting speaker output level ....	34
Adjusting the delay time .....	36
<b>Enjoying sound modes on the receiver .....</b>	<b>37</b>
Adjusting field of sound in the SFC mode .....	38
<b>VGCA mode .....</b>	<b>39</b>
<b>Other functions .....</b>	<b>40</b>
To mute the sound level .....	40
To listen through headphones .....	40
When using the VCR 2 terminals (front panel) .....	40
To turn off the blue light on the receiver and dim the processor's display .....	41
Setting the midnight mode (dynamic range compression) .....	41
<b>Making a recording .....</b>	<b>42</b>
Recording to a tape deck or VCR .....	42
<b>Using the remote control .....</b>	<b>43</b>
To operate the receiver .....	43
To operate the processor .....	45
To operate a cassette deck .....	46
To operate a CD changer or CD player .....	47
To watch TV broadcasts .....	48
To watch video tapes .....	49
To operate a DVD player .....	50
To watch satellite broadcasts .....	51
To watch cable TV .....	52
Changing the remote control code .....	53
<b>About the HELP function .....</b>	<b>60</b>
<b>If the front cover comes off .....</b>	<b>60</b>
<b>Technical specifications .....</b>	<b>61</b>
<b>Troubleshooting guide .....</b>	<b>62</b>
<b>Listening caution .....</b>	<b>Back cover</b>
<b>Maintenance .....</b>	<b>Back cover</b>
<b>Product service .....</b>	<b>Back cover</b>

## Supplied accessories



Please check and identify the supplied accessories.


- ☐ AC power supply cord (2 pc.)



(RJA0065-A)

- ☐ AM loop antenna set

- AM loop antenna (1 pc.)
- AM loop antenna holder (1 pc.)
- Screw (1 pc.)





(RSA0010)

- ☐ FM indoor antenna (1 pc.)



(RSA0006)

- ☐ Stereo connection cable (2 pc.)




(RJL2P004B08)

- ☐ Monaural connection cable (2 pc.)




(RJL1P011B15)

- ☐ Optical fiber cable (1 pc.)




(SJP2281)

- ☐ Batteries (4 pcs.)



- ☐ Remote control transmitter (1 pc.)



(RAK-SA954MK)

Use numbers indicated in parentheses when asking for replacement parts.

(Only for U.S.A.)

To order accessories contact 1-800-332-5368 or web site (<http://www.panasonic.com>).

THE FOLLOWING APPLIES ONLY IN THE U.S.A.

## CAUTION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any unauthorized changes or modifications to this equipment would void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## WARNING:

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR PRODUCT DAMAGE, DO NOT EXPOSE THIS APPLIANCE TO RAIN, SPLASHING, DRIPPING OR MOISTURE.

## CAUTION:

TO PREVENT ELECTRIC SHOCK MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.



**CAUTION**

RISK OF ELECTRIC SHOCK  
DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE SCREWS. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Before use

## Precautions

Before using this unit please read these operating instructions carefully. Take special care to follow the warnings indicated on the unit itself as well as the safety suggestions listed below. Afterwards keep them handy for future reference.


### Safety

1. **Power Source**—The unit should be connected to power supply only of the type described in the operating instructions or as marked on the unit.
2. **Polarization**—If the unit is equipped with a polarized AC power plug (a plug having one blade wider than the other), that plug will fit into the AC outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
3. **Power Cord Protection**—AC power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Never take hold of the plug or cord if your hand is wet, and always grasp the plug body when connecting or disconnecting it.
4. **Nonuse Periods**—When the unit is not used, turn the power off. When left unused for a long period of time, the unit should be unplugged from the household AC outlet.

### Installation

#### Environment

1. **Outdoor Antenna Grounding**—If an outside antenna is connected to the receiver, be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code, ANSI/NFPA No. 70-1990, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See figure below.



NEC—NATIONAL ELECTRICAL CODE

2. **Water and Moisture**—Do not use this unit near water—for example, near a bathtub, washbowl, swimming pool, or the like. Damp basements should also be avoided.
3. **Heat**—The unit should be situated away from heat sources such as radiators and the like. It also should not be placed in temperatures less than 5°C (41°F) or greater than 35°C (95°F).

### Placement

1. **Ventilation**—The unit should be situated so that its location or position does not interfere with its proper ventilation. Allow 10 cm (4") clearance from the rear of the unit.
2. **Foreign Material**—Care should be taken so that objects do not fall into and liquids are not spilled into the unit. Do not subject this unit to excessive smoke, dust, mechanical vibration, or shock.
3. **Magnetism**—The unit should be situated away from equipment or devices that generate strong magnetic fields.
4. **Stacking**—Do not place heavy objects, other than system components, on top of the unit.
5. **Surface**—Place the unit on a flat, level surface.
6. **Carts and Stands**—The unit should be used only with a cart or stand that is recommended by the manufacturer. The unit and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the unit and cart combination to overturn.
7. **Wall or Ceiling Mounting**—The unit should not be mounted to a wall or ceiling, unless specified in this operating instructions.



### Maintenance

Clean the cabinet, panel and controls with a soft cloth lightly moistened with mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzene.

### Service

1. **Damage Requiring Service**—The unit should be serviced by qualified service personnel when:
  - (a) The AC power supply cord or the plug has been damaged; or
  - (b) Objects have fallen or liquid has been spilled into the unit; or
  - (c) The unit has been exposed to rain; or
  - (d) The unit does not appear to operate normally or exhibits a marked change in performance; or
  - (e) The unit has been dropped, or the enclosure damaged.
2. **Servicing**—The user should not attempt to service the unit beyond that described in the operating instructions. All other servicing should be referred to an authorized service personnel.

**For the address of an authorized servicenter:**




**In the U.S.A. 1-800-211-7262 or web site**

**(<http://www.panasonic.com>)**

**In Canada 905-624-5505 or web site**

**([www.panasonic.ca](http://www.panasonic.ca))**


You are able to enjoy these surround systems with this system.

Surround system	Features	Software
<b>Dolby Pro Logic</b>	<p>Dolby Pro Logic is a decoding system that was developed to get a better sense of presence from sources encoded with Dolby Surround. The feeling of position has been improved by the addition of a separate center speaker channel. Dolby Surround was developed to allow enjoyment of Dolby Stereo, a cinema system, in private homes. This system reproduces sound close to that of the original movie through use of an analog matrix.</p> <p>(→ Page 26, 27.)</p>	<ul style="list-style-type: none"> <li>• Video tapes</li> <li>• Laser discs</li> <li>• DVDs</li> <li>• CDs</li> </ul> <p>Software encoded with Dolby Surround can be identified with this mark.</p> 
<b>Dolby Digital (AC-3)</b>	<p>Dolby Digital is a discrete 6 (5.1) channel digital surround system developed for cinema use. The sound signals in Dolby Digital format are compressed to 1/12 their original size, allowing an entire movie to be recorded on a single DVD. Not all Dolby Digital sources are recorded with 6 channels. Some sources marked Dolby Digital may be recorded in Dolby Surround, a 2 channel system.</p> <p>(→ Page 26.)</p>	<ul style="list-style-type: none"> <li>• DVDs</li> </ul> <p>Software encoded with Dolby Digital can be identified with this mark.</p> 
<b>DTS</b>	<p>DTS is a discrete 6 (5.1) channel digital surround system developed for cinema use. Sources encoded in DTS are only compressed to a quarter of the size of the original to preserve sound quality. DTS sources are produced with the intention that all speaker channels will be used.</p> <p>(→ Page 26.)</p>	<ul style="list-style-type: none"> <li>• DVDs</li> <li>• Laser discs</li> <li>• CDs</li> </ul> <p>Software encoded with DTS can be identified with this mark.</p> 
<b>SFC (Sound Field Control)</b>	<p>The receiver itself produces the surround effects with sources other than those listed above. Various effects, like a concert hall or jazz club, can be achieved by introducing width or reverberation to the original sound.</p> <p>(→ Page 27.)</p>	<p>Any kind, but particularly music CDs and video tapes.</p>

Manufactured under license from Dolby Laboratories. "Dolby", "Pro Logic" and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works. © 1992-1997 Dolby Laboratories, Inc. All rights reserved.

Manufactured under license from Digital Theater Systems, Inc. US Pat. No. 5,451,942 and other world-wide patents issued and pending. "DTS" and "DTS Digital Surround" are trademarks of Digital Theater Systems, Inc. © 1996 Digital Theater Systems, Inc. All rights reserved.

Receiver (SA-AX7)




No.	Name	Ref. page
-----	------	-----------

- ① Power "⏻/I" switch (POWER, ⏻/I) ..... 18  
Press to switch the unit from on to standby mode or vice versa.  
In standby mode, the unit is still consuming a small amount of power.
- ② Remote control signal sensor ..... 17
- ③ Help/reset button (-HELP, -RESET) ..... 60
- ④ Speaker select buttons  
(SPEAKERS A, B, **BI-WIRE**) ..... 18
- ⑤ Bi-amp indicator (BI-AMP) ..... 20
- ⑥ Adaptive subwoofer control/indicator  
(SUBWOOFER ADAPTIVE CONTROL) ..... 21
- ⑦ Subwoofer level control  
(SUBWOOFER LEVEL) ..... 21
- ⑧ Volume control (VOLUME) ..... 18
- ⑨ Input indicators ..... 18
- ⑩ VGCA mode select button/indicator  
(VGCA) ..... 39
- ⑪ Input selector (INPUT SELECTOR) ..... 18
- ⑫ Headphone jack (PHONES) ..... 40
- ⑬ TV/DSS, VCR 2 input select button  
( TV/DSS, VCR 2) ..... 40
- ⑭ VCR 2 terminals (VCR 2) ..... 10
- ⑮ Display

No.	Name	Ref. page
-----	------	-----------


- ⑯ Bass control (BASS) ..... 20
- ⑰ Treble control (TREBLE) ..... 20
- ⑱ Balance control (BALANCE) ..... 20
- ⑲ Bi-amp balance control  
(BI-AMP BALANCE) ..... 20
- ⑳ Subwoofer low pass filter control  
(SUBWOOFER LOW PASS FILTER) ..... 21
- ㉑ Front cover open button (PUSH OPEN) ..... 19
- ㉒ Tape monitor button (TAPE MONITOR) ..... 19
- ㉓ DVD 6ch input select button  
(DVD 6CH INPUT) ..... 29
- ㉔ Dolby Pro Logic/SFC mode off button  
(STEREO) ..... 37
- ㉕ Dolby Pro Logic mode/center mode select  
button (- PRO LOGIC,  
-CENTER MODE) ..... 27, 34
- ㉖ Band select/FM mode select button  
(-BAND, -FM MODE) ..... 22
- ㉗ Preset channel button (PRESET) ..... 25
- ㉘ Memory button (MEMORY) ..... 24
- ㉙ SFC mode select buttons  
(SFC **HALL CLUB LIVE THEATER SIMULATED**)  
..... 27
- ㉚ Tuning buttons (TUNING , ) ..... 22

# Processor (SH-AC500D)



No.	Name	Ref. page
31	Power button (POWER, $\blacksquare$ OFF $\blacktriangle$ ON) .....	28
32	Input select buttons/indicators (DIGITAL 1, DIGITAL 2, DIGITAL 3, LINE) .....	32
33	Standby indicator When the POWER button is in the ON position( $\blacktriangle$ ), the unit can be switched between the STANDBY and ON condition using the remote control and in this STANDBY condition the indicator will light.	
34	Display .....	26
35	Surround mode button (SURROUND) .....	29
36	Volume control (VOLUME) .....	28
37	Speaker setting button (CHANNEL/SET, SELECTOR) .....	26
38	DTS mode button (DTS) .....	26
39	Stereo mode button (STEREO) .....	26

## Speaker indicators and signal format indicators



### Speaker indicators

Light in accordance with the speaker setting, and each of the indicators corresponding with the speaker concerned flashes when;

- the type or presence of that speaker is set,
- the test signal is output from that speaker,
- the output level or delay time of that speaker is adjusted.

### Signal format indicators (LS, C, RS, L, R, S, LFE)

These indicators light up to indicate each input signal format.

LS: Surround speaker (left)

C: Center speaker

RS: Surround speaker (right)

L: Front speaker (left)

R: Front speaker (right)

"S" represents the mono surround and "LFE" (Low Frequency Effect) is a channel for the deep-bass effect in the low frequency range.

# Equipment connections

Make sure that the power supply for all components has been turned off before making any connections.

To connect equipment, refer to the appropriate operating instructions.

## Note

Do not place books, etc., on the top of this unit or block the heat radiation vents in any way.

## Connecting the receiver and processor


### Stereo connection cable (included)

White (L)   
Red (R) 


### Monaural connection cable (included)



Receiver (SA-AX7)



Processor (SH-AC500D)



AC power supply cord (included)

Connect this cord only after all other cables and cords are connected.

Household AC outlet (AC 120 V/60 Hz)

AC IN~ AC OUTLETS

### Cooling fan

The cooling fan operates at high power output levels only.

### "SWITCHED" AC outlets

Power to the outlet is controlled by the power switch of this unit. Audio equipment rated up to TOTAL 80 W can be connected here.

AC power supply cord (included)

Connect this cord only after all other cables and cords are connected.


AC OUTLET AC IN~

### "UNSWITCHED" AC outlet


This is for the exclusive use of an audio component. It can be used to supply power to a component regardless of whether the unit's POWER button is at the ON or OFF position. Use it for any unit having a rating of 50 W or less.



## Connecting a DVD player and other digital equipment



### Optical fiber cable connections **A**



- Do not bend the optical fiber cable.
- Attach the dust caps when the optical terminals are not in use.

### "DIGITAL 1" terminals **B**

Disconnect the coaxial cable from the DIGITAL 1 terminal when using an optical fiber cable. Only the coaxial cable is recognized if both types are connected.

### "LINE IN" terminals **C**


If "LINE" is selected with the input selector on this processor, the signals received through these terminals are output as they are without passing through any sound control circuits (i.e. no volume or other sound adjustments can be made with this processor.)

#### Note


- Dolby Digital RF (radio frequency) signals cannot be decoded with this processor even if a unit that has Dolby Digital RF output terminals is connected to this processor.
- Turn off the power to this processor if unusual hissing or beat sounds are heard while listening to FM, AM, or television broadcasts.

## Connecting audio and video equipment


Stereo connection cable (not included)




Video connection cable (not included)



Connecting to the VCR 2 terminals on the front panel



## Connections to/from S-VIDEO



### S-VIDEO cable (not included)



This receiver has an S-VIDEO terminal for a DVD player, VCR (VCR 1 only) and TV.

### Caution when using a TV with an S-VIDEO terminal

On some television models, the video signal from components which do not use S-VIDEO input and are connected only to the VIDEO terminals will not be shown on the television screen. If this occurs, use one of the following methods to view the video signal.

Does the television have a "VIDEO/S-VIDEO" selector switch?

YES

Set the switch to "VIDEO".

NO

**If the television has two or more video input terminals**

Connect the VIDEO terminal and the S-VIDEO terminal to different video input terminals on the television, and switch the picture on the television according to the video source being played.


**If the television has only one video input terminal**

Disconnect the S-VIDEO cable connected to the television's S-VIDEO terminal and connect only the video terminal.

### Note

When using S-VIDEO terminals be aware of the following. Video signals input into the VIDEO terminals cannot be output from S-VIDEO terminals or vice versa.

## Antenna connections



### FM indoor antenna (included) **A**

This antenna is normally sufficient for reception of FM broadcasts.

Attach to a wall (using tape) facing in the direction of best reception.

**For best reception**

An FM outdoor antenna is recommended.

### AM loop antenna (included) **B**

This antenna is normally sufficient for reception of AM broadcasts.



Fit the AM loop antenna holder (included) onto the rear panel of this unit and then attach the AM loop antenna to the AM loop antenna holder (facing in the direction of best reception).

Pay attention to the following points when mounting the antenna.


- Do not mount it close to power cords, speaker wires or metal surfaces (doing so will result in noise).
- Do not mount it close to a tape deck. When the tape deck is being used, chirping or beeping sounds may result.

### When mounting the antenna to a column, a wall or rack **C**

Mount the antenna so that the hinge is vertical.



**A**



**FM outdoor antenna (not included)**

**A**

An outdoor antenna should be used when using this unit in mountainous areas or in spaces enclosed by reinforced concrete where the FM indoor antenna (included) does not provide satisfactory reception. Disconnect the FM indoor antenna if an FM outdoor antenna is installed.

**Note**

An outdoor antenna should be installed by a qualified technician only.

**AM outdoor antenna (not included)**

**B**

An outdoor antenna should be used when using this unit in mountainous areas or in spaces enclosed by reinforced concrete where the AM loop antenna (included) does not provide satisfactory reception.


Stretch 5–12 m (16–40 ft.) of vinyl-covered wire horizontally across a window frame or other convenient location, keeping it as high as possible from the ground.

When the unit is not in use, disconnect the outdoor antenna to prevent possible damage that may be caused by lightning. Never use an outdoor antenna during an electrical storm.


**Note**

Be sure to connect the AM loop antenna even when an outdoor antenna is used.

**B**



## Placement of speakers



### Front speakers

Place the front speakers on the left and right of the TV at seated ear height so that there is good coherency between the picture and sound.

### Center speaker

Place this speaker underneath or above the center of the TV. Aim the speaker at the seating area.

### Surround speakers

Place these speakers on the side of or slightly behind the listener, and about one meter higher than ear level.

### Subwoofer


The subwoofer can be placed in any position as long as it is at a reasonable distance from the TV.

Note that some experimentation can yield the smoothest low frequency performance. Placement near a corner can increase the apparent output level, but can result in unnatural bass.

## Connecting speakers

Other connections are possible depending on your speaker system. See your speaker system's operating instructions for details.

### Front speakers




#### Note

Use the A terminals to enjoy Dolby Pro Logic, SFC, and DVD 6CH INPUT.

## Bi-wiring connection

### Note


When bi-wiring, use speakers designed for that purpose that have combined impedance of 6–8  $\Omega$



### Connecting the cables




**NO**



### Note

To prevent damage to circuitry, never short-circuit positive (+) and negative (-) speaker wires.


### If using a commercially available 4 mm plug cord



### Note

Fully tighten the speaker terminal, and then insert the end of the plug cable into the top of the terminal.



## Other speakers



### Speaker impedance:

Center speaker:	6-8 $\Omega$
Surround speaker:	6-8 $\Omega$
Subwoofer:	6-8 $\Omega$





## Battery installation

### Use of batteries

- Do not mix old and new batteries, or batteries of different types (manganese and alkaline, etc.).
- Never subject batteries to excessive heat or flame; do not attempt to disassemble them; and be sure they are not short-circuited.
- If the remote control is not to be used for a long period of time, remove the batteries and store them in a cool, dark place.
- Do not attempt to recharge alkaline or manganese batteries.
- Do not use rechargeable type batteries.
- Use alkaline batteries for longer life.


## Correct method of use

### Operation notes

- Do not place obstacles between the remote control signal sensor and remote control unit.
- Do not expose the remote control signal sensor to direct sunlight or to the bright light of an inverter fluorescent light.
- Take care to keep the remote control signal sensor and end of the remote control unit free from dust.
- If the unit is installed in a rack with glass doors, the glass doors' thickness or color might make it necessary to use the remote control a shorter distance from the unit.

### To prevent damage

- Never place heavy items on top of the unit.
- Do not disassemble or reconstruct the unit.
- Do not spill water or other liquids into the unit.



Before operation, set [VOLUME] to the "MIN" position.

### 1 Press [POWER].

### 2 Select the speaker system(s) to be used.

The buttons A, B and **BI-WIRE** refer to the speaker terminals at the rear of the unit.

If the button is pressed once more, the indicator will switch off and no sound will be heard from the speakers.

**BI-WIRE** and A, or **BI-WIRE** and B cannot be used at the same time.

### 3 Turn [INPUT SELECTOR] to select and start the desired source.

(Refer to the appropriate operating instructions for details.)

The indicator corresponding to the selected source lights and the source is shown on the display.

The selected source and "INPUT" will be shown on the display.

**TAPE (MONITOR):** To listen to cassette tapes

**VCR 1:** To watch video tapes (VCR 1)

**TV/DSS/VCR 2:** To watch TV, DSS or video tapes (VCR 2)

**VCR 3:** To watch video tapes (VCR 3)

**DVD:** To use the digital surround processor

**CD:** To listen to compact discs


**TUNER:** To listen to radio broadcasts

**PHONO:** To listen to phono discs

#### Note

To watch a video (or DVD) or the TV, set the TV to either the TV mode or VIDEO mode.

### 4 Adjust the volume level.



#### For your reference

##### • If a Dolby Pro Logic or SFC mode has been selected

After displaying the selected source, the display will then change to show the Dolby Pro Logic or SFC mode and "INPUT" will go out (➔ page 27).

If the source chosen was TUNER then the display will change again to show the frequency.

##### • If you are using VCR and you select TAPE, CD, TUNER, or PHONO


The picture will remain on the screen.

##### • The volume control

The volume control on this receiver allows more gradual adjustment compared to past models, thus making it easier to make fine volume adjustments during normal use.

#### When you finish listening

Be sure to reduce the volume level, and switch the power to the standby condition by pressing [POWER].



To open the front cover **A**

Press [PUSH OPEN].

Push the cover closed by hand.

For front speakers with an impedance under  $6\ \Omega$  **B**

Press and hold [A] or [B] until "LOW IMP" lights up on the display.

If even one of the speakers being used has an impedance under  $6\ \Omega$ , press and hold down either [A] or [B] for 4 seconds or more to set the impedance on the main unit to LOW.

(Press and hold down once again for 4 seconds or more to turn it off.)

Note that when "LOW IMP" is illuminated, speakers A and B cannot both be used at the same time.

To change speakers when "LOW IMP" is on:

e.g. To use speakers B, press [A] ("A" goes out), and then press [B] to activate speakers B.

The TAPE (MONITOR) indicator

This indicator lights in the following two situations:

1. While TAPE is selected.
2. While TAPE MONITOR is in use.


Tape monitor **C**

If [TAPE MONITOR] is pressed while a source other than TAPE is selected, the "TAPE (MONITOR)" indicator lights and the tape monitor comes on.

Sources other than tape can still be selected with [INPUT SELECTOR] while the "TAPE (MONITOR)" indicator is on.

Press [TAPE MONITOR] again to turn the tape monitor off.

(⇒ See "Making a recording" on page 42 for details on how to use the tape monitor during recording.)



### To enjoy bi-amp sound

**A**

By using the bi-wiring feature of this unit to connect your speakers, you are able to take advantage of two separate amplifiers for the high frequency and low frequency ranges. This enables more highly defined sound reproduction of the two ranges thus producing high quality bi-amp stereo sound.

Ensure "BI-AMP" illuminates when **BI-WIRE** is selected.

BI-AMP will turn off and the Indicator will go out in the following cases:

- If any of the Dolby Pro Logic or SFC modes are turned on.
- If DVD 6CH INPUT is selected.

### To adjust the high and low balance

Turn **[BI-AMP BALANCE]** to adjust the LF/HF balance

This adjusts the high and low frequency output of bi-wired front speakers.

The setting depends on the speakers being used.

Adjust the balance to suit your room's acoustics and the features of the speakers.

### To adjust the tone quality


**C**


Turn **[BASS]** to adjust the low frequency sound.  
Turn **[TREBLE]** to adjust the high frequency sound.

### To adjust the sound balance

**D**

Turn **[BALANCE]** to adjust the left/right sound balance.





### To adjust the subwoofer level A

Turn **[SUBWOOFER LEVEL]** to adjust its level.  
If the subwoofer isn't being used, be sure to set it to MIN.

### To compensate when the volume is low B

This button balances low volume sounds by boosting bass sound pressure of the front speakers and subwoofer.

This function allows you to enjoy balanced sounds even if the volume is low.

### Press **[SUBWOOFER ADAPTIVE CONTROL]**.

The message "ON" will appear on the display for 2 seconds.  
"SUBWOOFER ADAPTIVE CONTROL" will light up.

To return to the previous condition, press once again.

The message "OFF" will appear on the display for 2 seconds, then the indicator turns off.


### To adjust the output range of the subwoofer C


Turn **[SUBWOOFER LOW PASS FILTER]** to select a suitable frequency.

The setting depends on the room's acoustics, the peculiarities of the subwoofer, and the interaction of the subwoofer and the front speakers.


#### Note

Adjustments can not be made when DVD 6CH INPUT has been selected.





-BAND  
-FM MODE



## Sequential tuning

Use the tuning buttons to tune-in radio stations.

**1** Turn [INPUT SELECTOR] to select "TUNER."

**2** Press [-BAND, -FM MODE] to select "FM" or "AM."

**3** Press [TUNING ( V or ^ )] to tune to the desired frequency.

"TUNED" lights up when tuned.

"STEREO" lights up when an FM stereo broadcast is received.

### To make an automatic search for stations

If [TUNING ( V or ^ )] is held down for an instant until the frequency begins to scroll, the broadcast stations are tuned in automatically when one is found.

### Note

Tuning may stop automatically if any jamming is encountered.

### If noise is excessive in the FM stereo mode


Press and hold [-BAND, -FM MODE] for 2 seconds. ("STEREO" will go out, and "MONO" will light up).

The broadcast will be monaural, but noise will be reduced.

If the button is pressed and held for 2 seconds once more, the stereo mode resumes.

### For your reference

The tuner can pick up interference from DVD players. If this occurs turn the DVD player off.



## Direct tuning

### by remote control only

Specify the frequency using the numeric buttons on the remote control transmitter to directly tune to the desired station.

- 1 Press [RCVR] to switch to the receiver operation mode.  
The button lights up.

- 2 Press [TUNER].  
The selector on the receiver will change to "TUNER."  
Each time the button is pressed, the band will change as follows,  
FM  $\leftrightarrow$  AM.

- 3 Press [TUNE ENT].

- 4 While cursor display is flashing (approx. 10 seconds)  
Press the numbered buttons to enter the frequency.


If the desired FM frequency is 107.9 MHz, press




[1]  $\rightarrow$  [0]  $\rightarrow$  [7]  $\rightarrow$  [9].

If the frequency has been input correctly, the displayed frequency will blink once.

### Note

1. If no button is pressed while the cursor display is flashing, the display will return to the frequency which is currently being received.  
To re-specify the frequency, repeat the procedure from step 3.
2. If the frequency has not been input correctly, "ERROR" will be displayed.  
In this case, re-enter the frequency.





## Preset tuning

Presetting radio stations into the memory channels of this unit makes selecting stations simple.

A total of 30 FM and AM stations can be preset.

### Please remember this

If a new broadcast station is preset into a channel, the setting for the broadcast station which was previously entered in that channel will be automatically erased.

## Automatic memory presetting

Automatic memory presetting allows this unit to automatically search for broadcast stations and then preset them into memory. With this method, the channels that can be preset into the memory are set as follows for different bands (FM or AM).

### When FM stations are preset,

For FM stations ..... 1-30

### When FM and AM stations are preset,

For FM stations ..... 1-20

For AM stations ..... 21-30

**1** Set to the frequency from which you want to start automatic memory presetting.  
(⇒ Page 22-23.)

**2** Press [MEMORY] until the frequency begins to change.

(Automatic memory presetting will start.)

During automatic memory presetting, the memory indicator will flash while the frequency scrolls.

To stop, press [MEMORY] again.

### When a broadcast station is preset **A**

The memory indicator and the preset channel number will be displayed for approximately 1 second.

### When presetting is completed


The last broadcast station to be preset will be displayed.

### Note


Frequencies may not be preset correctly in cases where the broadcast waves are too strong or too weak. In such cases, carry out presetting manually. (⇒ Page 25.)




**A**




-BAND  
-FM MODE



**B**



PRESET



### Manual memory presetting **A**

Stations can be preset into the desired channels by the user.

#### 1 Set to the desired frequency.

(→ Page 22–23.)

If interference or static is keeping you from enjoying an FM broadcast, press and hold [-BAND, -FM MODE] and change to monaural.

You can preset the station in monaural just as in stereo.

#### 2 Press [MEMORY].

To cancel the memory function, press [MEMORY] again.

#### 3 Press [TUNING (V or ^)] to select the desired channel.

Holding the buttons down lets you scroll through channels faster.

#### 4 Press [MEMORY].

The channel will blink on the display.

#### To continue presetting

Repeat steps 1 through 4.

### To listen to preset channels **B**

#### 1 Press [PRESET].

#### 2 Press [TUNING (V or ^)].

Holding down the buttons lets you scroll through channels faster.

The channel number flashes for approximately 5 seconds. Select the desired channel number during that time.

After 5 seconds, the display will change from the channel number to the frequency.

#### Note

If you press [PRESET] while the channel number is displayed, the display will change to the frequency.

#### To confirm the channel number of the broadcast station being received

Press [PRESET].

(The channel number flashes for approximately 5 seconds.)

#### Note

The channel number is not displayed if you change the frequency or FM mode setting.



#### For your reference

Even if the power cord is disconnected from the household AC outlet, the memory will retain its contents for approximately one month.

#### If frequency presettings are accidentally erased

Program the presettings once again.

The power cord should remain connected for one hour or more for the memory back-up to be effective.



## On the processor

Use these modes to enjoy DVDs and other digital sources that have been connected to the processor through the digital optical terminals. The receiver should be in the DVD 6CH INPUT mode.

### SURROUND mode **A**

Select this mode when playing back sources (DVD, CD, laser disc, etc.) recorded in either Dolby Digital or Dolby Surround Format. The unit processes most types automatically. Normal audio CDs can also be played back. The unit processes the 2 channel signal into surround signals and sound is heard from all the speakers.

As well as normal audio CDs, software with any of the following marks can be played back in this mode.



### DTS mode **B**

Select this mode when playing back sources (DVD, CD, laser disc, etc.) recorded in DTS format.

Software with the following mark can be played back in this mode.



### STEREO mode **C**

Select this mode to listen to surround sources, other than DTS, in stereo. The down-mix function of this unit concentrates the discrete signals into the front L/R channels. Use this mode when using headphones or recording onto a video cassette recorder. Select this mode to listen to normal stereo software.

## On the receiver

Use these modes to enjoy any source (video tapes, CDs, etc.) other than DVD 6CH INPUT.

### Dolby Pro Logic SURROUND mode **A**

By reproducing the feeling of depth and movement of sound, video software or compact discs recorded with Dolby Surround provide the listener with a feeling of presence like that of a movie theater.

### Dolby Pro Logic 3 STEREO mode **B**

You can enjoy audio/video sources with clear sound, more presence and a good feeling of orientation. 3 STEREO can be used with stereo sources not encoded with Dolby Surround.

### SFC mode **C**

The SFC (Sound Field Control) function gives presence and spread thereby enhancing and enriching the music or movie. Read the following explanations to better understand how to make your selection.

#### Note

- SFC is designed to add surround-like effects to stereo sources. Select the Dolby Pro Logic SURROUND mode when playing back Dolby Surround sources.
- The center speaker is not used in the HALL and SIMULATED mode

#### HALL

This mode imparts a reflection and spread which will make you feel as if you are in a large concert hall.

#### CLUB

Like a jazz club, this mode provides an exciting and intimate atmosphere. It simulates the sound field of a relatively small room having a low ceiling and hard reflective surfaces, for a "live" sound with enhanced presence to bring the performers up close.

#### LIVE

Primarily for vocal pieces, this mode adds gloss to the vocals and you'll feel as though you were hearing a live stage performance.

#### THEATER



You can clearly perceive the directions and source of the movie. Real ambience of sound can also be recreated naturally using this mode.



#### SIMULATED (SIM SURR)

Choose this mode if little or no sound will be heard from the surround speakers.

You can feel as if you were in a more expanded space adding to the actual sound from the source.

This mode also adds effect to monaural sources by outputting sound from surround speakers.





## Speaker settings for the processor

Set the type and presence of the speakers before playing the sound by reproducing the input source.

### Before proceeding

Check the frequency range of each speaker to be used. Consider speakers capable of playing back low frequency sounds (below around 100 Hz) as **LARGE**. Consider speakers not capable of playing back low frequency sounds as **SMALL**.

**1** Press [POWER].

**2** Press [CHANNEL/SET], and select the speaker channel to be set.

Each time the button is pressed, the channel display is switched in the listed order.

**FRONT:** Front speakers

**CENTER:** Center speaker

**SURROUND:** Surround speakers

**SUB-WFR:** Subwoofer

**COMPLETE:** Select this when you have completed the settings.

The selected channel is shown on the display for approx. 2 seconds. The current setting for that channel is then shown as a flashing display. The indicator corresponding to the selected speaker also continues to flash.

**3** Press [SELECTOR], and set the type (**LARGE**, **SMALL**) and presence (**YES**, **NO** or **NONE**) of the speaker.

Each time the button is pressed, the display is switched in the listed order.

**LARGE:** select if the speaker can produce low frequency sounds,

**SMALL:** select if the speaker cannot produce low frequency sounds,

**NONE:** select if you are not using a center speaker or surround speakers,

**YES:** select if you are using a subwoofer,

**NO:** select if you are not using a subwoofer.

The sound for speaker channels that are set to "NONE" or "NO" are output from the front speakers.

**4** Repeat steps 2 and 3 to complete the settings for all the channels.

**5** Press [CHANNEL/SET] to select "COMPLETE."




The settings are now entered into the unit's memory. The display goes out after about 2 seconds and the previous display reappears.

The speaker indicators light up unless "NONE" or "NO" has been selected for the corresponding channel.

If no buttons are pressed for approx. 10 seconds during the setting process, all previous settings are cancelled, the setting mode is released, and the original display is restored. Begin the setting process again if this occurs.

### For your reference

The setting remains as it is until changed by the above procedure, even after the power has been turned off.



## Adjusting speaker output level

Adjust speaker level so the output from all the speakers is the same apparent level when sitting where you would normally enjoy a source.

### Preparation for the receiver

- Turn ON the speakers with [A] or [BI-WIRE].
- Adjust front speaker balance with [BALANCE].

**1** Turn [INPUT SELECTOR] to select "DVD" on the receiver.

**2** Press [DVD 6CH INPUT] to select "DVD-6CH." Changes as follows, each time the button is pressed.  
DVD 6CH  $\rightleftharpoons$  DVD (2CH)

If you press this button while another source (CD, PHONO, etc.) is selected, the receiver switches the source to DVD and engages the DVD 6CH INPUT mode.

**3** Set the volume level to 0 dB on the processor.

**4** **by remote control only**

Press [PROC] to switch to the processor operation mode.  
The button lights up.

**5** **by remote control**

Press [SURROUND] to select the surround mode.  
"SURROUND" appears on the display.


**6** **by remote control only**

Press [TEST] to output the test signal.  
"TEST" appears on the display, and the speaker indicator corresponding to the speaker outputting sound flashes.  
The test signal is automatically output from each speaker for 2 seconds in the following sequence:

L  $\rightarrow$  C  $\rightarrow$  R  $\rightarrow$  RS  $\rightarrow$  LS  $\rightarrow$  SW

- L: Front speaker (left)
  - C: Center speaker
  - R: Front speaker (right)
  - RS: Surround speaker (right)
  - LS: Surround speaker (left)
  - SW: Subwoofer
- (Speakers for which NONE or NO has been set are skipped.)

(Continued on next page)



**7 by remote control**

Press [VOL -] or [VOL +] to set the receiver's volume level normally used for enjoying the source.

**8 by remote control only**

Press [LEVEL CH SELECT] to select the speaker channel to adjust.

The output level appears on the display, and the speaker indicator for the selected speaker flashes.


Each time the button is subsequently pressed, the speaker whose level is to be set is selected in the listed sequence. (Speakers for which NONE or NO has been set are skipped.)

**9 by remote control only**

Press [LEVEL ∇] or [LEVEL ▲] to adjust the output level.


Channels C, RS, LS, and SW can be adjusted between -12 dB and +12 dB. Set them so that the output from each channel appears to be the same as that from the front speakers.

**10 Repeat steps 8 and 9 to adjust the output of each channel to approximately the same apparent level.**



**To stop the test signal**

Press [TEST].



## Adjusting the delay time

### by remote control only

By adjusting the delay time, the difference in the distance from the viewing and listening position to the front speakers and the distance to the center speaker and surround speakers can be offset and made equal. This achieves better sound localization and makes a more life-like reproduction of the sound field possible.

#### Note

Please note that the following occurs if delay time is adjusted while playing back a source or analog input is selected:

- Adjustment is not possible if the source is DTS format.
- While the **PRO LOGIC** indicator is alight, the center channel cannot be adjusted and 15 ms are added to the delay times listed for the surround channel.

**1** Press [PROC] to switch to the processor operation mode.  
The button lights up.

**2** Press [SURROUND] to select "SURROUND."  
"SURROUND" appears on the display.

**3** Press [DELAY CH SELECT] to select the channel to be adjusted.  
The current delay time is displayed.  
The speaker indicator for selected speaker flashes.  
Press again to change the speaker channel;  
C (Center speaker) ↔ S (Surround speakers)

Speakers set as "NONE" are skipped.

**4** Press [DELAY ∇] or [DELAY ▲] to set the delay time.  
The delay time changes with each press.  
The increments depend on the channel being adjusted.

Speaker	Available delay time setting (ms)
Center	0, 1, 2, 3, 4, 5
Surround	0, 5, 10, 15

The display is restored if a button isn't pressed for 4 or more seconds.

### To calculate the delay time **A**



D1: Distance from front speakers  
D2: Distance from surround speakers  
D3: Distance from center speaker



#### Setting the center channel delay time:

If D1 is equal to or less than D3	Set to 0 ms
If D3 is less than D1	Increase 1 ms for every 30 cm of difference between D1 and D3

#### Setting the surround channel delay time:

If D1 is equal to or less than D2	Set to 0 ms
If D2 is less than D1	Start at 0 ms and increase by 5 ms for every 1.5 m of difference between D1 and D2





Dolby Digital, DTS and other 6 channel discrete sources are recorded with each speaker channel discrete from the other. Depth, movement, position and other characteristics are maintained, so using this mode will make you feel as if you were at a movie theater.

Ensure you have your speakers set up in either of the following ways.

- The front speakers are connected to the A terminals (➡ page 14) and "SPEAKERS A" is selected.
- The front speakers are bi-wired (➡ page 15) and "SPEAKERS BI-WIRE" is selected.

**1** Turn [INPUT SELECTOR] to select "DVD" on the receiver.

**2** Press [DVD 6CH INPUT] to select "DVD 6CH" on the receiver.

### Note

- This mode cannot be turned on while SPEAKERS B is on. This mode is automatically cancelled if SPEAKERS B is selected and the modes in the memory for all sources will also be switched to STEREO. The modes must be selected again for all sources when SPEAKERS B is turned off again.

- BI-AMP and DVD 6CH INPUT cannot be used at the same time.

If you are using BI-AMP and you select DVD 6CH INPUT, BI-AMP will turn OFF and the "BI-AMP" indicator will go out.

**3** Press one of the processor's input select buttons to select the input source.

The indicator above the pressed button now lights.

**DIGITAL 1:** Selects the source connected to the DIGITAL 1 terminal. The unit automatically recognizes whether the source is connected through the optical fiber cable or the coaxial cable.

### Note

If both types are connected at the same time, only the coaxial cable is recognized. Disconnect the coaxial cable if the external unit is connected with the optical fiber cable.

**DIGITAL 2:** Selects the source connected to this terminal.

**DIGITAL 3:** Selects the source connected to this terminal.

**LINE:** Selects the source connected to the LINE terminal.

**When DIGITAL 1, 2 or 3 has been selected:**

The reproduction modes in step 4 can be selected.

**When LINE has been selected:**


The analog sound signals input through LINE IN terminals are directly output to the connected component. "THROUGH" appears on the display.

### Note

Only the POWER button and select buttons function when LINE has been selected.


(Continued on next page)






4


SURROUND



DTS




STEREO




5


a



b



c



- 4 Press [SURROUND], [DTS] or [STEREO] to select the reproduction mode.

The selected reproduction mode appears on the display (→ page 26 for descriptions of the modes.)

- 5 Start the desired source.

Follow your equipment's operating instructions.

#### The surround indicators

a DIGITAL: Lights if the source is Dolby Digital Format.

b DTS: Lights if the source is DTS format.


c PRO LOGIC: Lights when Dolby Surround parts of Dolby Digital format software are played back, or when playing audio CDs in the SURROUND mode.

Only Dolby Digital, DTS or PCM signals\* can be reproduced through the digital terminal:

- The digital input signal of sampling frequencies 96 kHz and other signal formats such as MPEG cannot be reproduced on this unit.
- When playback is started, the sound may be cut or interrupted before the input source is confirmed as Dolby Digital or DTS.

\* PCM signal: This refers to the recording format of signals (44.1 kHz, linear 16 bits) used for audio CDs.

Sound mode (Surround on the processor)



## Setting the center mode and adjusting speaker output level

Adjust speaker level so the output from the center and surround speakers is the same apparent level when sitting where you would normally enjoy a source.

### Preparation

- Turn ON the speakers with [A] or [BI-WIRE].
- Adjust front speaker balance with [BALANCE].

### 1 Press [-DOLBY PRO LOGIC, -CENTER MODE] to select "SURROUND."

Each time the button is pressed, the Dolby Pro Logic mode will change as follows

SURROUND ⇌ 3 STEREO.

#### Note

1. Select "3 STEREO" if surround speakers have not been connected.
2. Remember, you cannot adjust the output level of the surround speakers if you selected "3 STEREO" mode.

### 2 Press and hold [-DOLBY PRO LOGIC, -CENTER MODE] to select the correct center mode.

When the button is pressed and held, the current center mode is displayed.

Pressing it again changes the center mode.

#### NORMAL

When the center speaker is smaller than the front speakers.

#### WIDEBAND


When the center speaker is the same size as or larger than the front speakers.

#### PHANTOM **SURROUND mode only**


When no center speaker is connected.

#### Note

In the PHANTOM mode, the sound which would have been sent to the center speaker will be divided equally between both the left and right front speakers.



(Continued on next page)



### 3 by remote control only

Press [RCVR] to switch to the receiver operation mode.  
The button lights up.

### 4 by remote control only

Press [TEST] to output a test signal.  
The speaker outputting the test signal is displayed while the test is running.  
L : Front speaker (left)  
C : Center speaker  
R : Front speaker (right)  
S : Surround speakers

The subwoofer is muted while testing.

In the PHANTOM mode, the center speaker is OFF, so there is no center test signal and "C" is not displayed.

### 5 by remote control

Press [VOL -] or [VOL +] to set the volume level normally used for enjoying the source.

### 6 by remote control only

Press [LEVEL] to select the center or surround speakers.

### 7 by remote control only

Press [◀] or [▶] to adjust the output level to the same apparent level as the front speakers.

– : Decrease the output level.

+ : Increase the output level.

Output level can be varied within a range of –12 dB to +12 dB with front speaker output level serving as the zero point.

#### Note


During steps 6 and 7 above the test signal sequence is interrupted and the signal will only come from the selected speaker.




The sequence will resume when adjustments are stopped.

### 8 Repeat step 6 and 7 for each speaker channel.

To stop the test signal  
Press [TEST].

To turn off the Dolby Pro Logic systems  
Press [STEREO].





## Adjusting the delay time

### by remote control only

Adjust the sound from the surround speakers until the proper effect is produced.

**1** Press [RCVR] to switch to the receiver operation mode.  
The button lights up.

**2** Press [SURROUND].

#### Note

This procedure can be done only in the SURROUND mode.

**3** Press [DELAY].  
When the button is pressed, the current delay time is displayed.

**4** Press [◀] or [▶] to set the time.

The delay time changes by 5 ms with each press, between 15 and 30 ms.

The standard setting is 20 ms.

### To calculate the delay time **A**

D<sub>1</sub>: Distance from front speakers


D<sub>2</sub>: Distance from surround speakers

• If D<sub>1</sub> is equal to or less than D<sub>2</sub>

Set to 15 ms.

• If D<sub>2</sub> is less than D<sub>1</sub>

Start at 15 ms and increase by 5 ms for every 1.5 m of difference between D<sub>1</sub> and D<sub>2</sub>.



Ensure you have your speakers set up in either of the following ways.

- The front speakers are connected to the A terminals (➔ page 14) and "SPEAKERS A" is selected.
- The front speakers are bi-wired (➔ page 15) and "SPEAKERS BI-WIRE" is selected.

- 1 Turn [INPUT SELECTOR] to select the source.**
- 2 Start the source.**
- 3 Select the mode.**  
The selected reproduction mode appears on the display.  
(➔ Page 27 for descriptions of the modes.)


**To turn off the Dolby Pro Logic or SFC functions**  
Press [STEREO].

## For your reference



You can set the sound mode for each source.  
Each source will retain the selected mode.

## Note



- These modes cannot be turned on while SPEAKERS B is on. These modes are automatically switched to STEREO if SPEAKERS B is selected and the modes in the memory for all sources will also be switched to STEREO. The modes must be selected again for all sources when SPEAKERS B is turned off again.
- BI-AMP and Dolby Pro Logic, BI-AMP and any of the SFC modes cannot be used at the same time.  
If you are using BI-AMP and you select a Dolby Pro Logic or SFC mode, BI-AMP will turn OFF and the "BI-AMP" indicator will go out.
- You cannot select Dolby Pro Logic or any of the SFC modes while in the DVD 6CH INPUT mode.



**A**



**B**



## Adjusting field of sound in the SFC mode

### by remote control only

With this unit, you can adjust speaker volume.  
Adjust the field of sound while listening to a source.

### To adjust the volume of each speaker **A**

- 1** Press [RCVR] to switch to the receiver operation mode.  
The button lights up.
  - 2** Press [LEVEL] to select the speaker channel to adjust.  
The output level appears on the display.
- Note**  
You can adjust center speaker volume only in THEATER mode
- 3** Press [◀] or [▶] to adjust the output level.  
Channels C and S can be adjusted between -12 dB and +12 dB.

### To adjust the delay time of the surround speakers **B**

- 1** Press [RCVR] to switch to the receiver operation mode.  
The button lights up.
- 2** Press [DELAY].  
When the button is pressed, the current delay time is displayed.
- 3** Press [◀] or [▶] to set the time.  
Each press changes the delay time.  
Increments depend on the mode.  
Select a delay time setting to accommodate to your individual needs.


SFC modes	Available delay time setting (ms)
HALL	20, 25, 30, <b>40</b> , 50
CLUB	0, <b>15</b> , 20, 25, 30
LIVE	15, 20, 30, 40, <b>50</b>
THEATER	15, <b>20</b> , 25, 30, 40
SIMULATED	<b>15</b> , 20, 25, 30, 40

The figures in bold italics are the factory settings.

### For your reference

Settings for volume level and delay time can be done for each SFC mode.

## VGCA mode



This receiver features a state-of-the-art variable gain control amplifier (VGCA). This feature cuts down greatly on noise encountered during normal use.

**1** Turn [INPUT SELECTOR] to select the source.

**2** Press [VGCA].

The "VGCA" indicator lights when "VGCA" is selected. "VGCA ON" is displayed, then "TONE DEFEAT / DISPLAY OFF" scrolls across the display. The display then turns off. If TUNER was chosen as the source, the current frequency is shown.

**3** Start the desired source.

Follow your equipment's operating instructions.

### To confirm the current display

Press [STEREO].

The display comes on for about 3 seconds.

### For your reference

You can set the VGCA mode for each source.

Each source will retain the selected mode.

### Note


- Tone quality (bass and treble) cannot be adjusted in this mode.
- Dolby Pro Logic and the SFC modes cannot be selected while VGCA is on. These modes are also cancelled when VGCA is turned on and STEREO mode is engaged.

### To have the display on constantly


The display is turned off while VGCA is on to cut down on unnecessary noise. Do the following if you would prefer to have the display on.

- ① Turn [INPUT SELECTOR] to select a source other than TUNER.
- ② Press [VGCA] to turn VGCA on.
- ③ Press and hold [VGCA] for about 4 seconds until the display comes on.


This setting remains active even if the unit is turned off. Repeat the procedure to turn the display off again.



## Other functions



○ VCR 2  
■ TV/DSS



### To mute the sound level

by remote control only

Press [MUTING].

The message "MUTING ON NOW" runs repeatedly from right to left across the display as long as the muting function is on.

Press once again to return to the previous volume level.

#### Note

Muting is cancelled when the receiver is turned off.

### To listen through headphones

- ① Reduce the volume level.
- ② Connect the headphones.  
Plug type: 6.3 mm (1/4 in.) stereo
- ③ Adjust the volume level.

Turn the speakers off when using headphones. Turning the speakers off automatically engages STEREO mode and ensures no sound is heard from the subwoofer. If either SURROUND or 3 STEREO is used, the sound heard through the headphones will seem unusual.

#### Note

Avoid listening for prolonged periods of time to prevent hearing damage.


### When using the VCR 2 terminals (front panel)

This button can be used only when TV/DSS/VCR 2 is selected as the input source.


The TV/DSS, VCR 2 input select button works for both TV/DSS input and input from the source connected to the front panel "VCR 2" terminals.

(→ Page 10.)

Select "■ TV/DSS" or "■ VCR 2".







## To turn off the blue light on the receiver and dim the processor's display A

### by remote control only

This can improve video viewing in dark or dimly lit rooms.

- ① **Press [PROC].**  
The button lights up.
- ② (Point the remote control toward the receiver and processor)  
**Press [DIMMER].**  
When the button is pressed, the blue light on the receiver is turned off and the display on the processor is dimmed.

Repeat to turn on again.

### Note

- When the unit's power is turned off, the original condition is restored.
- If one of the conditions is not changed, turn the system off to return it to the original setting and repeat the steps again carefully.

## Setting the midnight mode (dynamic range compression) B

### by remote control only

"Dynamic range compression" (DR COMP) is a function for compressing the dynamic range (reproduction level range) of audio signals. It is used for viewing movie software late at night or at other times when high volume levels are not desirable.

This function only works with DR COMP compatible Dolby Digital format software.


- ① **Press [PROC].**  
The button lights up.
- ② **Press [DR COMP].**  
The "DR COMP" indicator lights.

When the procedure is repeated, the function is released, and the indicator goes off.




### For your reference

When DR COMP is on, scenes that already have a low sound level will be heard as they are. When scenes that are loud occur, the function acts to reduce the peak level.

The sound field will remain intact even if DR COMP is functioning.



## Making a recording



### Note

When you select DVD 6CH INPUT mode, only sound from the front left and right channels is recorded.

### To record all 6 channels

Set the playback mode on the processor to STEREO mode.  
(➔ Page 26.)

## Recording to a tape deck or VCR

You can record to a tape deck connected to TAPE REC (OUT) or to a VCR connected to VCR 1 OUT.

See the recording unit's operating instructions for details on how to prepare it for recording.

When recording with a tape deck, you can record any source except TAPE.

When recording with a VCR, you can record any source except TAPE or VCR 1.

### Note

Recording from the tape deck to the VCR is not possible.

- 1 Turn [INPUT SELECTOR] to select the source to be recorded.
- 2 If you selected TV/DSS/VCR 2 in step 1, set [TV/DSS, VCR 2] to the required position.
- 3 Begin recording.  
Follow your recording unit's operating instructions.
- 4 Start the source to be recorded.  
Follow your equipment's operating instructions.

### To monitor sound being recorded onto a tape deck

It is possible to check the sound being recorded if your tape deck is a 3 head system.

Press [TAPE MONITOR] on this unit and set the monitor button on the tape deck to "TAPE."


Press [TAPE MONITOR] once again to turn it off.

### For your reference

Use the VCR 2 terminals on the front of the unit when dubbing from a video camera.

## To operate the receiver

Point the remote control toward the receiver



### Basic operations

To turn on/off



Once the unit has been set to on, it can be turned on and off simply by pressing [ ].

To switch the remote control to each operation mode



or



or



To reconfirm the remote control operation mode



To select an input source



or



or



#### Note

- PHONO and VCR 3 can not be selected with this remote control.
- TAPE MONITOR cannot be controlled with the [TAPE] button.

To mute the sound level



The message "MUTING ON NOW" runs repeatedly from right to left across the display as long as the muting function is on. Press once more to return to the original volume.

To adjust the volume level



To turn on/off the blue light




DIMMER

The processor's display also dims (brightens) if faced towards the processor at the same time.

To operate the receiver (continued)

Point the remote control toward the receiver



### Surround modes

To turn on the Dolby Pro Logic SURROUND mode



**Note**

3 STEREO can not be selected with this remote control.

To turn off the Dolby Pro Logic and SFC mode



To turn SFC on and select the mode



Changes as follows each time the button is pressed.

HALL -- CLUB -- LIVE -- THEATER  
SIMULATED


To output a test signal



When the SURROUND or 3 STEREO mode is on

Press once more to stop the test signal.


To select the speaker channel and adjust its output level



- ① Select center (C) or surround (S).
- ② Adjust output level.

- When the SURROUND mode is on and the center mode is on PHANTOM, you cannot select the center channel.
- When SFC is used, the center mode can be changed only if THEATER is on.
- When the 3 STEREO mode is on, you cannot select the surround channel.

To adjust delay time



When the SURROUND or SFC modes are on


### To listen to radio broadcasts

To select "FM" or "AM"




Change as follows each time the button is pressed.  
FM ↔ AM

To select the desired channel sequentially (Preset tuning)



To select the desired channel directly (Preset tuning)



(Example: Channel 1)

①

(Example: Channel 10)


①

②

③

within 10 seconds

To select radio stations by frequency (Direct tuning)



(Example: 107.9 MHz)

①

②


③

④

within 10 seconds

## To operate the processor

Point the remote control toward the processor



To turn on/standby



To select the input source




To select the SURROUND mode




To select the STEREO mode




To output a test signal




To select the speaker channel and adjust its output level



To select the speaker channel and adjust its delay time



To adjust the volume balance between the left and right front speakers



To turn the midnight mode on



This function only works with DR COMP compatible Dolby Digital format software.








To dim the display



The receiver's blue light also goes off (comes on) if faced towards the receiver at the same time.











## To operate a cassette deck

Turn the cassette deck ON before trying to operate it by remote control.  
It may not be possible to operate some cassette decks with this unit.

<p>Point the remote control toward the cassette deck</p>  	<p><b>To switch the remote control to the cassette deck operation mode</b></p>	
	<p>Only when using a double cassette deck <b>To select the tape deck (DECK 1/DECK 2)</b></p>	
	<p><b>To start playback</b></p>	
	<p><b>To fast-forward or rewind the tape</b></p>	<p>While the tape is stopped</p>  <p>With TPS-equipped cassette decks, you can move to the beginning or end of a track by pressing these buttons while the tape is playing.</p>
	<p><b>To stop playback</b></p>	

## To operate a CD changer or CD player


Turn the CD changer (or CD player) ON before trying to operate it by remote control.  
It may not be possible to operate some CD players with this unit.

<p>Point the remote control toward the CD changer (or CD player)</p>  	<p>To switch the remote control to the CD changer (or CD player) operation mode</p>	
	<p>To start play</p>	
<p>[CD changer only] To start play from the desired disc</p>		<p>For 5 CD changer</p>  <p>Select disc number.</p>
		<p>For MEGA CD changer ※</p>  <p>Select the disc number. (When selecting discs, [≥10] does not respond to touch.)</p>
	<p>To start play from the desired track</p>	<p>Select the track number. (Example: Track 1)</p>  <p>(Example: Track 10)</p> 
	<p>To skip a track</p>	
	<p>To stop play</p>	

※ "MEGA CD changer" means any Technics CD changer that takes more than 50 discs.

## To watch TV broadcasts

The procedures below are examples for when a TV and VCR are connected to the receiver as shown in this manual.



### To watch TV broadcasts

Point the remote control toward the receiver

RCVR → [Power] →  
**Switch ON the receiver.**


Point the remote control toward the receiver and the TV

TV → [Power] →  
**Switch ON the TV**  
The receiver will switch to TV/DSS/VCR 2 input.

Point the remote control toward the TV

TV/VIDEO → [Power] →  
**Set the TV/VIDEO mode on the TV to "TV".**

Point the remote control toward the TV



**Select the desired channel.**

### To watch TV broadcasts with a VCR tuner

Point the remote control toward the receiver

RCVR → [Power] →  
**Switch ON the receiver.**


Point the remote control toward the TV

TV → [Power] →  
**Switch ON the TV.**

Point the remote control toward the TV

TV/VIDEO → [Power] →  
**Set the TV/VIDEO mode on the TV to "VIDEO".**

Point the remote control toward the VCR



**Select the desired channel.**

Point the remote control toward the VCR and the receiver

Set the input selector on the VCR to the "TUNER" position

VCR → [Power] →

**Switch ON the VCR.**

The receiver will switch to VCR 1 input.

### To switch OFF the TV

TV → [Power] →


### To switch OFF the VCR

VCR → [Power] →



## To watch video tapes

The procedures below are examples for when a TV and VCR are connected to the receiver as shown in this manual.



### To watch video tapes

Point the remote control toward the receiver



Switch ON the receiver.

Point the remote control toward the TV



Switch ON the TV.

Point the remote control toward the TV



Set the TV/VIDEO mode on the TV to "VIDEO".

Point the remote control toward the VCR



Playback will begin.

Point the remote control toward the VCR and the receiver



Switch ON the VCR.

The receiver will switch to VCR 1 input.

To fast-forward or rewind the video tape

In the stop mode




To start recording



To stop playback or recording temporarily



To stop playback or recording



To switch OFF the TV




To switch OFF the VCR



## To operate a DVD player

The procedures below are examples for when a TV and DVD player are connected as shown in this manual. Actual operations depend on your equipment and software.



### To watch DVDs

Point the remote control toward the receiver



Switch ON the receiver.

Point the remote control toward the TV



Switch ON the TV.

Point the remote control toward the TV



Set the TV/VIDEO mode on the TV to "VIDEO".

Point the remote control toward the DVD player.



Play will begin.

Point the remote control toward the DVD player and receiver



Switch ON the DVD player. The receiver will switch to DVD input.

#### To select the title

DVD TITLE



Play will begin.

#### To use the DVD menu

DVD MENU



Play will begin.

#### To clear the DVD menu

DVD MENU




**To use on-screen graphic controls**  
(Graphic user interfaces, GUI, are a feature of some DVD players. See your player's manual for details.)

DISPLAY



or




Play will begin.

#### To skip to the beginning of a track or chapter



#### To stop play



#### To switch OFF the TV




#### To switch OFF the DVD player



## To watch satellite broadcasts

The procedures below are examples for when a TV and satellite receiver are connected.  
To operate the satellite receiver, you must set up the codes. (➔ Page 53 and 54.)



Point the remote control toward the receiver




Switch ON the receiver.

Point the remote control toward the TV




Switch ON the TV.

Point the remote control toward the TV



Set the TV/VIDEO mode on the TV to "VIDEO".

Point the remote control toward the satellite receiver



Select the desired channel.

Point the remote control toward the satellite receiver and the receiver



Switch ON the satellite receiver.

The receiver will switch to DVD input.

To switch OFF the TV




To switch OFF the satellite receiver



## To watch cable TV

The procedures below are examples for when a TV and cable box are connected.  
To operate the cable box, you must set up the codes. (⇒ Page 53 and 54.)



Point the remote control toward the receiver




Switch ON the receiver.

Point the remote control toward the TV




Switch ON the TV.

Point the remote control toward the TV



Set the TV/VIDEO mode on the TV to "VIDEO".

Point the remote control toward the cable box



Select the desired channel.

Point the remote control toward the cable box and receiver



Switch ON the cable box.

The receiver will switch to DVD input.

### To switch OFF the TV



### To switch OFF the cable box




## Changing the remote control code

Change the remote control code in either of the following circumstances:

- If the Panasonic TV or VCR does not operate as a result of a difference in the remote control code.
  - If you wish to operate some other make of TV, VCR, DVD player, satellite receiver or cable box.
- (⇒ Refer to pages 48 to 52 for the buttons which can be used.)

### Note


- Even after changing the code there may be cases where certain operations cannot be done or operation is not possible at all.
- Changes to the codes may be cancelled when the remote control's batteries are replaced. Repeat the operation to reenter the code.
- This remote control can only accept the code for either a DVD player or a satellite receiver or a cable box. It will be able to control only the component you have entered the code for.



## How to change the remote control code

- 1 Find the code numbers for your device in the code tables.**  
(⇒ pages 55 to 59).


- 2 Press the button for the component you want to operate.**




- 3 Press [SET UP].**  
Both the green and red indicator light up.



- 4 Press the button for the component you want to operate again.**




- 5 Carefully enter the 4 digit code.**  
The buttons at the top of the remote control flash to indicate the number has been accepted.  
Repeat from step 2 if the number wasn't accepted.









- 6 Press [ ] to test operation.**  
If the correct code was entered, the component will turn on or off.  
Try the code. If the component doesn't respond, repeat from step 2 and try the next code.



## Changing the remote control code (continued)



### Using the code scan to change the remote control code

- 1 Press [SET UP].**  
 Both the green and red indicator light up.
 
- 2 Press the button for the component you want to operate.**  
 Only the red indicator lights up.
 
- 3 Press [0] twice.**

- 4 Press [ ] repeatedly until the component responds.**  
 Be sure to leave enough time between presses for the component to respond.
 
- 5 Press [SET UP] immediately after the component responds.**  
 The code is locked into the remote control.
 
- 6 Press [ ] again to check that the code has been accepted.**


### For your reference

#### Checking the code numbers you have entered.

Use this feature to make a note of the codes you have entered for each component.

- ① Press [SET UP].**  
 Both the green and red indicators light up.
- ② Press the button for the component you want to confirm.**  
 Only the red indicator lights up.
- ③ Press [≥10].**  
 The green indicator flashes to show the code number. It pauses between each digit. 10 flashes represents "0".  
 The red indicator goes out to show the number is finished.

# TV code lists

<b>A Mark</b> 4100	<b>Electrohome</b> 4075 4099 4100 4000 4003 4009 4042 4062	<b>JVC</b> 4086 4074 4069 4076 4048
<b>Action</b> 4013	<b>Emerson</b> 4054 4069 4013 4012 4153 4043 4085 4084 4011 4000 4083 4071 4154 4004 4038 4155 4100 4003 4009 4016 4035 4042 4046 4056 4058 4059 4072 4073 4109 4113 4115 4150	<b>Kawasho</b> 4066 4024 4109 4098
<b>Admlral</b> 4132 4052 4053 4077 4085 4084	<b>Envision</b> 4024 4009	<b>Kenwood</b> 4009 4115 4000 4024 4040 4078 4096
<b>Advent</b> 4159	<b>Fisher</b> —Also see LXI/Sanyo/Sears 4093 4066 4068 4039 4047 4107 4088	<b>Kloss Novabeam</b> 4017 4125
<b>Akai</b> 4075 4066 4009 4000	<b>Fortress</b> 4009	<b>KMC</b> 4100
<b>Anam</b> 4011	<b>Funai</b> —Also see Daewoo/Goldstar/ Magnasonic/Nikko 4013 4029 4011 4058 4158	<b>KTV</b> 4143 4013 4109 4016 4100 4011 4024 4042
<b>Anam National</b> 4017	<b>Futurtech</b> 4011	<b>Lloyds</b> 4115 4099 4112
<b>AOC</b> 4024 4000 4006 4042 4100 4122 4129	<b>Garrard</b> 4158	<b>Logik</b> 4052 4132 4138 4137
<b>Audiovox</b> 4013	<b>GE</b> 4133 4069 4076 4134 4063 4077 4080 4025 4017 4027 4040 4000 4006 4008 4011 4019 4026 4028 4042 4100 4124 4150	<b>LXI</b> —Also see Fisher/Sanyo/Sears 4133 4053 4077 4000 4106 4158 4028
<b>Baycraft</b> —Also see Baycrest 4060 4059 4042 4084	<b>Goldstar</b> —Also see Daewoo/Funai/Magnasonic/ Nikko 4052 4014 4134 4106 4122 4000 4024 4121 4009 4042 4100 4112 4051 4101 4105	<b>Magnasonic</b> —Also see Daewoo/Funai/Goldstar/ Nikko 4085 4000 4009 4058 4129
<b>Bell &amp; Howell</b> 4053 4132 4052 4085	<b>Gradiente</b> 4065	<b>Magnavox</b> 4053 4086 4076 4043 4125 4090 4009 4105 4082 4085 4000 4015 4042 4116 4003 4021 4024 4035 4049 4058 4059 4103 4104 4108 4110
<b>Broksonic</b> 4053 4067 4113 4000 4002 4011 4114	<b>Granada</b> 4060 4100 4105	<b>Marantz</b> 4053 4043 4009 4024 4040 4042 4105 4106
<b>Candle</b> —Also see Citizen 4086 4053 4069 4059 4129 4100 4101 4148 4000 4011 4024 4042 4051 4058 4114 4116	<b>Grundig</b> 4076 4043 4139 4057 4079 4100	<b>Matsushita</b> —Also see Panasonic 4091
<b>Citek</b> 4149	<b>Hallmark</b> 4000	<b>Megatron</b> —Also see Hitachi 4060
<b>Citizen</b> —Also see Candle 4086 4114 4148	<b>Harley Davidson</b> —Also see RCA 4077	<b>Memorex</b> 4132 4000 4001 4034 4062 4088 4099 4106 4156
<b>Classic</b> 4066 4000	<b>Harman Kardon</b> 4000	<b>MGA</b> —Also see Mitsubishi 4075 4132 4062 4009
<b>Colortyme</b> 4053 4069 4044 4077 4115 4009 4018 4096 4097 4105 4090	<b>Hitachi</b> 4152 4118 4060 4076 4077 4100 4119 4129 4072 4099 4010 4031 4033 4036 4042 4085	<b>Mitsubishi</b> —Also see MGA 4075 4151 4062 4099 4000 4127 4009 4005 4024 4001 4036 4042 4091 4100 4105 4111 4117
<b>Concherto</b> 4053	<b>Infinity</b> 4105	<b>MTC</b> 4053 4069 4024 4129 4000 4018 4088 4109 4125
<b>Contec Cony</b> 4013 4011 4109 4046 4073	<b>Inteq</b> —Also see Zenith 4052 4050	<b>Multivision</b> 4143 4081
<b>Craig</b> 4069 4013 4114 4011 4035 4056 4059	<b>JBL</b> 4105	<b>NAD</b> 4034
<b>Crosley</b> 4053	<b>JC Penney</b> 4069 4076 4077 4028 4024 4025 4000 4006 4106 4107 4055 4100 4121	<b>NEC</b> 4043 4042 4009 4096 4115 4024 4040 4097
<b>Crown</b> 4059 4100	<b>Jensen</b> —Also see NEC 4009 4083	<b>Nikko</b> —Also see Daewoo/Funai/Goldstar/ Magnasonic 4129
<b>Curtis</b> 4000 4090 4123		
<b>Curtis Mathes</b> 4133 4053 4132 4069 4077 4070 4009 4024 4042 4100 4101		
<b>CXC</b> 4013 4011		
<b>Daewoo</b> —Also see Funai/Goldstar/Magnasonic/ Nikko 4142 4086 4130 4129 4024 4017 4100 4150 4000 4042 4090 4101 4123		
<b>Daytron</b> 4100 4035 4042 4123 4129		
<b>Denon</b> 4152		

## TV code lists

<b>Nishi</b> 4069	<b>Remocon</b> 4101	<b>Tatung</b> 4017 4037 4114
<b>Nyon</b> 4028 4000	<b>Rent-Co</b> 4090	<b>Technics</b> —Also see Panasonic 4118 4076 4080 4043 4117 4145 4057 4092
<b>Onwa</b> 4011	<b>Runco</b> 4132 4148	<b>Teckwood</b> 4053 4009
<b>Optimus</b> —Also see Radio Shack/Realistic 4126	<b>Sampo</b> 4118 4017 4024 4042	<b>Teknika</b> 4132 4013 4059 4011 4024 4149 4040 4042 4100 4112 4129
<b>Orion</b> 4153 4084	<b>Samsung</b> 4069 4074 4157 4024 4100 4000 4042 4085 4102	<b>Telefunken</b> 4115
<b>Panasonic</b> —Also see Matsushita 4142 4118 4076 4013 4070 4077 4080 4043 4017 4117 4027 4030 4056 4055 4025 4057 4092 4129 4140 4148 4158	<b>Sansui</b> 4061	<b>TMK</b> 4009 4000 4115
<b>Philco</b> 4053 4086 4043 4090 4085 4009 4015 4059 4125 4000 4003 4021 4024 4035 4042 4058 4082 4103 4104 4105 4108 4110 4129	<b>Sanyo</b> —Also see Fisher/LXI/Sears 4068 4039 4088 4022 4047 4107	<b>Toshiba</b> 4093 4086 4069 4107 4111 4039 4106 4131
<b>Phillips</b> 4053 4086 4105	<b>Scott</b> 4054 4013 4100 4011 4042 4058 4082 4084	<b>Totevision</b> 4077
<b>Pioneer</b> 4023 4043 4126 4120 4017 4040 4042	<b>Sears</b> —Also see Fisher/LXI/Sanyo 4093 4133 4053 4060 4077 4068 4039 4028 4047 4000 4107 4011 4022 4045 4016 4088 4100	<b>Ultra</b> 4129
<b>Portland</b> 4100 4101 4000 4024 4042 4123	<b>Sharp</b> 4135 4041 4061 4087 4128 4020 4033 4090 4116 4100 4047 4085 4089 4094 4099 4115 4122	<b>Video Concepts</b> 4091 4011
<b>Prima</b> 4101 4138	<b>Signature 2000</b> 4132 4087 4039	<b>Videokron</b> 4136 4147 4146
<b>Prism</b> 4043	<b>Silver</b> 4000 4009	<b>Vidliron</b> 4053 4136
<b>Proscan</b> —Also see RCA 4133 4134 4077	<b>Simpson</b> 4000 4009	<b>Vidtech</b> 4024
<b>Proton</b> 4077 4000 4100 4009 4114 4007 4018 4033 4042 4059 4095 4106	<b>Sony</b> 4064 4066 4041 4144 4098 4100	<b>Viewmax</b> 4101
<b>Pulsar</b> 4129 4000 4018 4042 4106 4112 4113	<b>Soundesign</b> 4059 4000 4003 4011 4042 4072 4083	<b>Wards</b> 4132 4086 4050 4053 4069 4077 4061 4025 4000 4024 4085 4090 4042 4104 4020 4026 4058 4059 4106
<b>Quasar</b> 4142 4118 4076 4080 4043 4017 4030 4117 4035 4055 4057 4092 4119	<b>SSS</b> 4009 4011 4024	<b>XR 1000</b> 4132 4158
<b>Radio Shack</b> —Also see Optimus/Realistic 4053 4013 4077 4068 4061 4011 4034 4017 4020 4032 4087 4099 4100 4141	<b>Sylvania</b> 4053 4086 4043 4090 4104 4009 4108 4015 4110 4059 4125 4021 4082 4000 4003 4024 4035 4042 4045 4058 4103 4105 4116 4129	<b>Yamaha</b> 4043 4024 4059 4115 4129
<b>RCA</b> —Also see Proscan 4133 4023 4069 4134 4063 4077 4080 4028 4006 4017 4092 4011 4025 4026 4027 4040 4042 4100 4124	<b>Symphonic</b> 4012 4013 4029 4158 4058	<b>Zenith</b> 4052 4050 4132 4044 4014 4129 4158
	<b>Tandy</b> 4053	



# VCR code lists

<b>Action</b> 6103	<b>Go Video</b> 6019 6020 6031 6032 6116 6118 6010	<b>Minolta</b> 6038
<b>Admiral</b> 6101	<b>Goldstar</b> —Also see Daewoo/Funai/Magnasonic/Nikko	<b>Mitsubishi</b> —Also see MGA
<b>Alwa</b> 6028	6048 6043 6007 6128 6008 6010 6041 6056	6067 6127 6013 6122 6043 6034 6053 6112 6083 6090
<b>Akal</b> 6025 6011 6016 6049 6059	<b>Gradiente</b> 6035	<b>MTC</b> 6031 6028 6057
<b>Beaumont</b> 6010	<b>Granada</b> 6013 6004 6053	<b>Multitech</b> 6028 6057
<b>Bell &amp; Howell</b> 6058	<b>Hitachi</b> 6012 6038 6063 6119 6028 6040 6092 6065 6113	<b>NEC</b> 6048 6007 6091 6096 6094 6056 6028 6045 6006 6050 6051 6065 6074 6078
<b>Broksonic</b> 6054 6075 6124 6066 6117 6004 6093 6095 6123	<b>Homeline</b> 6043	<b>Optimus</b> —Also see Radio Shack/Realistic
<b>Candle</b> —Also see Citizen	<b>JBL</b> 6086	6061 6043 6128 6121
6043 6103 6014 6027 6028 6040 6004 6010 6023 6024 6056 6072	<b>JC Penney</b> 6038 6031 6043 6027 6010 6070	<b>Panasonic</b> —Also see Matsushita
<b>Canon</b> 6027 6109	<b>Jensen</b> 6050 6052	6129 6043 6031 6027 6068 6109 6096 6107 6014 6081 6082 6071 6073 6108 6110 6130
<b>Capehart</b> 6024 6104	<b>JVC</b> 6035 6012 6047 6038 6096 6074 6050 6078 6003 6026 6058 6097	<b>Pentax</b> 6038 6094
<b>Citizen</b> —Also see Candle	<b>Kenwood</b> 6069 6006 6050 6058 6094	<b>Philco</b> 6017 6027 6068 6004 6028 6033 6057 6082
6014 6027 6028 6040 6072	<b>Lloyds</b> 6028 6094 6057 6072 6108	<b>Philips</b> 6014 6027 6068 6004 6033 6082
<b>Colortyme</b> 6081 6096 6027 6080	<b>Logik</b> 6031 6079	<b>Pioneer</b> 6106 6009 6033 6121
<b>Craig</b> 6031 6043 6108 6120	<b>LXI</b> —Also see Sears/Sanyo/Fisher	<b>Portland</b> 6024 6104
<b>Criterion</b> 6031	6057 6028	<b>Pro Max</b> 6128
<b>Curtis Mathes</b> 6027 6014 6081 6109 6040 6006 6010 6023 6028 6051 6082 6094	<b>Magnasonic</b> —Also see Daewoo/Funai/Goldstar/Nikko	<b>Proscan</b> —Also see RCA
<b>Daewoo</b> —Also see Funai/Goldstar/Magnasonic/Nikko	6031 6043 6103	6105 6081 6107
6005 6103 6014 6104 6024 6023 6099	<b>Magnavox</b> 6035 6017 6031 6027 6068 6014 6096 6109 6004 6082 6028 6033 6055 6071 6074	<b>Proton</b> 6031
<b>Daytron</b> 6103 6024 6104	<b>Magnin</b> —Also see MGN	<b>Pulsar</b> 6128 6027 6103 6010 6072 6028 6098
<b>Denon</b> 6038	6010	<b>Quasar</b> —Also see Technics
<b>Dynatech</b> 6014 6065	<b>Marantz</b> 6017 6004 6045 6056 6082 6094	6043 6129 6068 6027 6109 6081 6082 6115
<b>Electrohome</b> 6067 6013 6043 6122 6004 6053	<b>Marta</b> 6043	<b>Radio Shack</b> —Also see Optimus/Realistic
<b>Emerson</b> 6075 6054 6007 6043 6124 6013 6014 6066 6081 6088 6018 6095 6125 6023 6028 6037 6071 6078 6097 6004 6053 6055 6058 6117 6123 6126	<b>Matsui</b> 6028	6043
<b>Fisher</b> —Also see LXI/Sanyo/Sears	<b>Matsushita</b> —Also see Panasonic	<b>RCA</b> —Also see Proscan
6069 6014 6108 6062 6015 6039 6058 6065	6027	6038 6089 6105 6013 6069 6131 6081 6107 6068 6027 6096 6040 6073 6092 6010 6003 6009 6074 6076 6077 6099
<b>Funai</b> —Also see Daewoo/Goldstar/Magnasonic/Nikko	<b>MEI</b> 6065	<b>Realistic</b> —Also see Optimus/Radio Shack
6057 6028 6072	<b>Memorex</b> 6085 6048 6038 6043 6046 6108 6000 6022 6058	6085 6061 6043 6027 6108 6028 6030 6002 6010 6053 6062 6082
<b>Garrard</b> 6028	<b>MGA</b> —Also see Mitsubishi	<b>Samsung</b> 6128 6010 6040 6072 6028 6073
<b>GE</b> 6019 6081 6027 6068 6040 6010 6082 6092 6097	6013	<b>Sansui</b> 6031 6074 6095
<b>Genexxa</b> 6028	<b>MGN</b> —Also see Magnin	<b>Sanyo</b> —Also see Fisher/Sears
	6010	6085 6069 6108 6058 6015 6039 6062
	<b>Midland</b> 6072	<b>Scott</b> 6043 6054 6075 6014 6018 6071

## VCR code lists

<b>Sears</b> –Also see Fisher/Sanyo 6085 6038 6043 6069 6027 6014 6039 6028 6015 6058 6062 6108 6045 6074 6083 6102	<b>Symphonic</b> 6028 6057 6050 6108 6002 6045 6072	<b>Ultra</b> 6104
<b>Sharp</b> 6061 6046 6101 6030 6002 6051 6053 6076	<b>Tatung</b> 6050 6074	<b>Unitec</b> 6072 6073
<b>Shintom</b> 6031	<b>Teac</b> 6028	<b>Vector Research</b> 6094
<b>Signature 2000</b> 6085 6101	<b>Technics</b> 6027 6096 6110 6111	<b>Video Concepts</b> 6083 6094
<b>Singer</b> 6031	<b>Teknika</b> –Also see Panasonic 6043 6027 6028 6076	<b>Wards</b> 6061 6043 6014 6046 6028 6030 6002 6004 6010 6053 6108
<b>Sony</b> 6086 6087 6029 6021 6016 6065 6084 6113 6044 6064 6098 6050	<b>Thomas</b> 6028	<b>XR 1000</b> 6031 6028
<b>Sylvania</b> 6027 6109 6028 6004 6057 6082 6033 6071	<b>TMK</b> 6023	<b>Yamaha</b> 6050 6094
	<b>Toshiba</b> 6013 6014 6103 6100 6114 6015 6036 6060 6084 6108	<b>Zenith</b> 6048 6047 6025 6043 6040 6059 6057
	<b>Totevision</b> 6043 6109	

## DVD player code lists

<b>Denon</b> 6132	<b>Panasonic</b> 6132	<b>Sony</b> 6135
<b>Faroudja</b> 6133	<b>Proscan</b> –Also see RCA 6134	<b>Toshiba</b> 6133
<b>Magnavox</b> 6133	<b>RCA</b> –Also see Proscan 6134	<b>Yamaha</b> 6132
<b>Mitsubishi</b> 6133	<b>Samsung</b> 6133	<b>Zenith</b> 6133
<b>Onkyo</b> 6133		


## SAT code lists

<b>Alphastar</b> 3064 3028	<b>HTS</b> 3041	<b>RCA</b> 3051
<b>Birdview</b> 3026	<b>Hughes</b> 3058 3024 3018	<b>Realistic</b> 3014
<b>Chaparral</b> 3043 3019	<b>Intersat</b> 3042	<b>Rural Cable</b> 3004
<b>CI Satellite</b> 3025	<b>Janell</b> 3011	<b>Samsung</b> 3064
<b>Datron</b> 3056	<b>Kenwood</b> 3013	<b>Sony</b> 3056
<b>DISH Network</b> 3061	<b>Legend</b> –Also see Echostar 3020	<b>Star Trak</b> 3055 3054 3010 3009
<b>Drake</b> 3053 3047 3044 3037 3035 3031 3023 3001	<b>M/A Com</b> 3015 3008 3002 3001	<b>STS</b> 3007
<b>DX Communications</b> 3045 3033	<b>ORB</b> 3027	<b>SuperGuide</b> 3029 3017
<b>Echostar</b> –Also see Legend 3049 3048 3040 3032 3020	<b>Panasonic</b> 3062 3000	<b>Tee-Com</b> 3057
<b>Equus</b> 3038	<b>Pansat</b> 3052 3022	<b>Toshiba</b> 3060 3015 3001
<b>Fujitsu</b> 3011	<b>Primestar</b> 3033	<b>Uniden</b> 3063 3039 3036 3034 3030 3021 3017 3016 3014 3012 3005 3003
<b>GE</b> 3051	<b>Proscan</b> 3051	<b>Video Pall</b> 3011
<b>General Instruments</b> 3046 3015 3008 3006 3004	<b>Quick Draw</b> 3045	<b>Viewstar</b> 3050
<b>Hitachi</b> 3059 3018	<b>Radio Shack</b> 3014 3006 3004	<b>Zenith</b> 3011

# CBL code lists

<b>ABC</b> 2013 2016 2018 2053 2010 2011 2030 2031 2034 2038 2048	<b>Magnavox</b> 2002 2048	<b>Scientific Atlanta</b> 2066 2053 2021 2077 2010 2080
<b>AIM</b> 2047	<b>Memorex</b> 2020 2031 2034 2038 2075	<b>Sears</b> 2046
<b>Archer</b> 2049 2034 2060	<b>Micro Com</b> 2078	<b>Signal</b> 2027
<b>Belcor</b> 2060	<b>Monarch</b> 2027	<b>Signature 2000</b> 2048
<b>BRX</b> 2046	<b>Movie Time</b> 2013 2033 2027 2034	<b>Sony</b> 2003
<b>Cableview</b> 2043	<b>Northcoast</b> 2036	<b>Sprucer</b> 2014 2036
<b>Century</b> 2034	<b>NSC</b> 2013 2004 2012 2033 2034	<b>Starcom</b> 2016 2018 2050 2048 2032 2047 2023 2026 2044 2070 2071 2075
<b>Citizen</b> 2049 2027 2034 2047	<b>Oak</b> 2012 2038 2025 2041 2079	<b>Stargate</b> 2047 2027
<b>Contec</b> 2005 2015 2021 2028 2053 2041 2012 2014 2038 2042	<b>Panasonic</b> 2020 2005 2014 2037	<b>Sylvania</b> 2029 2046 2065
<b>CPI</b> 2040	<b>Paragon</b> 2020 2031 2034	<b>Telecaption</b> 2067
<b>Diamond</b> 2041	<b>Philips</b> 2054 2056 2072 2044 2001 2024 2031 2034 2055 2061	<b>Tele View</b> 2027
<b>Eagle</b> 2031	<b>Pioneer</b> 2030 2037	<b>Texscan</b> 2062 2029 2065
<b>Eastern</b> 2006	<b>Proscan</b> 2068	<b>Tocom</b> 2013 2000 2011 2033 2010 2012 2014
<b>GC Electronics</b> 2049 2058 2019 2027 2034 2052	<b>Pulsar</b> 2027 2049	<b>U.S.Electronics</b> 2053 2018 2048
<b>Gemini</b> 2047 2039 2043 2076	<b>Radio Shack</b> 2034 2049 2060	<b>Unika</b> 2034
<b>General Instruments</b> 2050 2016 2028 2070 2022 2048	<b>RCA</b> 2068	<b>United Cable</b> 2016
<b>Hamlin</b> 2041 2073 2017	<b>Recoton</b> 2069	<b>Universal</b> 2069 2051 2071 2034 2049 2060
<b>Hitachi</b> 2046 2048	<b>Regal</b> 2041	<b>Viewstar</b> 2064 2031 2035 2055 2063 2010
<b>Jasco</b> 2049	<b>Regency</b> 2042	<b>Wards</b> 2048
<b>Jerrold</b> 2009 2016 2028 2050 2040 2015 2048 2045 2031 2022 2023 2057 2059	<b>Rembrant</b> 2012	<b>Warner</b> 2030
<b>JVC</b> 2009	<b>Samsung</b> 2027 2030	<b>Wave Master</b> 2008
		<b>Zenith</b> 2020 2036 2074

**A**



If you make a mistake in operation or if sound output stops due to some operation which was performed, the *HELP* function displays information which can be useful for indicating the method by which this condition can be remedied.

If "ERROR" or scrolling characters (for instance, "SPEAKER OFF NOW") appear on the display during operation, carry out the following operation.

### Press [-HELP, -RESET].

The method for remedying this situation will be displayed.

### For your reference

If the above button is pressed for 2 seconds or more until "RESET" appears on the display, the operation settings for the unit will be initialized to the settings made at the time of shipment.


However, any broadcasting stations which have been preset into memory will not be erased at this time.

-HELP  
-RESET



## If the front cover comes off

**B**



- ① Insert the cover as shown in the illustration.
- ② Ensure the cover is parallel to the unit, then press firmly down on the levers until they click into place.
- ③ Check that the cover now moves correctly.  
If it does not, remove it and repeat the above procedure.

## RECEIVER

### ■ AMPLIFIER SECTION

**Rated minimum sine wave RMS power output**  
**20 Hz–20 kHz both channels driven**  
**0.05 % total harmonic distortion**

100 W per channel (6 Ω)

1 kHz continuous power output both channels driven

0.05 % total harmonic distortion 105 W per channel (6 Ω)

**Total harmonic distortion**

rated power at 20 Hz–20 kHz 0.05 % (6 Ω)

half power at 1 kHz 0.03 % (6 Ω)

**Power output at the DVD 6CH operation**

20 Hz–20 kHz (each channels driven)

0.09 % total harmonic distortion

Front 2 x 100 W (6 Ω)

Center 100 W (6 Ω)

Surround 2 x 100 W (6 Ω)

Subwoofer 20–200 Hz 100 W (6 Ω)

**Low frequency damping factor** 30 (6 Ω)

**Load impedance**

Front

A or B 4–8 Ω

A and B 8 Ω

BI-WIRE 6–8 Ω

Center 6–8 Ω

Surround 6–8 Ω

Subwoofer 6–8 Ω

**Dynamic headroom** 2 dB (8 Ω)

**Frequency response**

PHONO RIAA standard curve ±0.8 dB

CD, TAPE, DVD, VCR 1, TV/DSS/VCR 2, VCR 3

10 Hz–100 kHz, ±3 dB

**Input sensitivity**

PHONO 0.4 mV (3 mV, IHF'66)

CD, TAPE, DVD, VCR 1, TV/DSS/VCR 2, VCR 3

27 mV (200 mV, IHF'66)

**S/N (IHF A) (VGCA ON)**

PHONO 80 dB (80 dB, IHF'66)

CD, TAPE, DVD (L/R/C/LS/RS), VCR 1, TV/DSS/VCR 2, VCR 3

90 dB (100 dB, IHF'66)

110 dB (IHF A, Rated Power, S=2 V)

**Input impedance**

PHONO 47 kΩ

CD, TAPE, DVD, VCR 1, TV/DSS/VCR 2, VCR 3 22 kΩ

**Tone controls**

BASS 50 Hz, +10 to –10 dB

TREBLE 20 kHz, +10 to –10 dB

**Adaptive control (volume at –30 dB)** 50 Hz, +5 dB

**Subwoofer cut off frequency control** 50–200 Hz

### ■ FM TUNER SECTION

**Frequency range** 87.9–107.9 MHz

**Sensitivity** 11.2 dBf (2 μV, IHF'58)

**50 dB quieting sensitivity**

MONO 18.3 dBf (4.5 μV, IHF'58)

STEREO 38.3 dBf (45 μV, IHF'58)

**Total harmonic distortion**

MONO 0.2 %

STEREO 0.3 %

**S/N**

MONO 73 dB

STEREO 67 dB

**Frequency response** 20 Hz–15 kHz, +1 dB, –2 dB

**Alternate channel selectivity** 65 dB

**Capture ratio** 1.5 dB

**Image rejection at 98 MHz** 40 dB

**Spurious response rejection at 98 MHz** 75 dB

**AM suppression** 50 dB

**Stereo separation**

1 kHz 40 dB

10 kHz 30 dB

**Antenna terminal** 75 Ω (unbalanced)

### ■ AM TUNER SECTION

**Frequency range** 530–1710 kHz

**Sensitivity** 20 μV, 330 μV/m

**Selectivity** 55 dB

**IF rejection at 1000 kHz** 50 dB

### ■ VIDEO SECTION

**Output voltage at 1 V input (unbalanced)** 1±0.1 Vp-p

**Maximum input voltage** 1.5 Vp-p

**Input/output impedance** 75 Ω

### ■ GENERAL

**Power supply** AC 120 V, 60 Hz

**Power consumption** 340 W

(In standby condition: 2 W)

**Dimensions (W x H x D)** 430 x 158 x 378.4 mm

(16-15/16" x 6-7/32" x 14-29/32")

**Weight** 11 kg (24.4 lb.)

### ■ DIN Power (1 kHz T.H.D. 1%)

2 x 100 W (6 Ω)

## SURROUND PROCESSOR

### ■ AUDIO

**Output voltage/impedance** 2 V (at 0 dB)/1 kΩ

**Input impedance**

LINE 22 kΩ

COAXIAL 75 Ω

**Frequency response**

FRONT L/R, CENTER, SURROUND L/R (LARGE)

20 Hz–20 kHz ±1 dB

**Delay time**

DOLBY DIGITAL CENTER 0–5 ms

SURROUND L/R 0–15 ms

DOLBY PRO LOGIC SURROUND L/R 15–30 ms

**Total harmonic distortion**

FRONT L/R (1 kHz, 0 dB, PCM) 0.007 %

**Dynamic range**

S/N (IHF A) 96 dB

**Load impedance** 100 dB

More than 10 kΩ

### ■ GENERAL

**Power supply** AC 120 V, 60 Hz

**Power consumption** 15 W

(In standby condition: 4 W)

**Dimensions (W x H x D)** 430 x 69.4 x 301.4 mm

(16-15/16" x 2-47/64" x 11-55/64")

**Weight** 2.6 kg (5.7 lb.)

### Notes:

1. Specifications are subject to change without notice.

Weight and dimensions are approximate.

2. Total harmonic distortion is measured by the digital spectrum analyzer.

Before requesting service for this unit, check the chart below for a possible cause of the problem you are experiencing. Some simple checks or a minor adjustment on your part may eliminate the problem and restore proper operation.

If you are in doubt about some of the check points, or if the remedies indicated in the chart do not solve the problem, refer to the directory of Authorized Service Centers (enclosed with this unit) to locate a convenient service center, or consult your dealer for instructions.

**For detailed instructions, contact an authorized servicer in the U.S.A. and Panasonic Canada Inc. Customer Care Centre in Canada.**

**In the U.S.A. 1-800-211-7262 or web site**

**(<http://www.panasonic.com>)**

**In Canada 905-624-5505 or web site**

**([www.panasonic.ca](http://www.panasonic.ca))**

Problem	Probable cause(s)	Suggested remedy	Page(s)
---------	-------------------	------------------	---------

## While listening to FM broadcasts


Hiss is heard during stereo broadcasts, but not during monaural ones.	Modulation for the two types is different so some noise may be heard during stereo broadcasts.	<ul style="list-style-type: none"> <li>• Reduce the treble.</li> <li>• Change the location and direction of the antenna.</li> <li>• Use an outdoor antenna.</li> <li>• Use an antenna with more elements.</li> </ul>	20 12,13
Excessive noise in both stereo and monaural broadcasts.	Antenna location and direction poor.	<ul style="list-style-type: none"> <li>• Use an outdoor antenna.</li> <li>• Use an antenna with more elements.</li> </ul>	13
	Station is distant.		-
"STEREO" and "TUNED" indicators flicker.	Antenna location and direction poor.	<ul style="list-style-type: none"> <li>• Change the location and direction of the antenna.</li> <li>• Use an outdoor antenna.</li> <li>• Use an antenna with more elements.</li> </ul>	12,13
	Station is distant.		13
Stereo broadcasts highly distorted.	Building or mountain nearby.	<ul style="list-style-type: none"> <li>• Use an antenna with more elements.</li> </ul>	-

## While listening to AM broadcasts

Unusual "beat" sound is heard.	A television is on nearby.	• Separate the two or turn the television off.	-
	Adjacent signal is interfering.	• Reduce the treble.	20
Low-pitched "hum" is heard when a station is tuned.	Power cord is near the antenna wires.	• Separate the power cord from the wires.	-
	Electronic interference from the power cord is fed to the speakers.	• Use an outdoor antenna.	13
A continuous or intermittent hiss is heard.	Interference from other appliances.	• Separate this unit from such appliances.	-

## While enjoying the surround modes

Sound is not heard from the center, surround or subwoofer speakers.	The presence setting of the speaker has been incorrectly set to "NONE" or "NO."	• Set the type and presence setting of each speaker correctly.	28
	The STEREO reproduction mode is on.	• Set to SURROUND or DTS reproduction mode.	33
A DTS formatted source cannot be played back in the SURROUND mode.	This DTS source couldn't be processed by the SURROUND mode.	• Select the DTS reproduction mode.	33
Sound doesn't come from the center speaker while using Dolby Pro Logic.	PHANTOM is selected.	• Select NORMAL or WIDEBAND.	34

Problem	Probable cause(s)	Suggested remedy	Page(s)
<b>Common Problems</b>			
Unit doesn't come on.	The power cord plug is not fully inserted.	• Confirm the plug is fully inserted.	–
Sound is not heard.	The speaker indicators are off.	• Turn on the speaker indicators.	18
	The tape monitor function is on.	• Press the tape monitor button.	19
	The muting function is on.	• Press the muting button on the remote control.	40
	Incomplete or incorrect connection to speakers and external equipment.	• Check all connections.	8–11, 14–16
	The incorrect input source has been selected.	• Select the correct source.	18, 32
The midnight mode does not function. (When the DR COMP button on the remote control is pressed, the DR COMP indicator does not light.)	The SURROUND mode has not been selected.	• Select the SURROUND mode.	33
	The source being played has not been recorded in the Dolby Digital format.	• Check if the  DIGITAL indicator is illuminated.	41
Sound suddenly stops or none is heard when the unit is switched on. "OVERLOAD" appears on the display.	The protection circuitry has functioned because: the positive and negative speaker wires have shorted; speakers with a lower impedance than this unit's rated impedance are being used; the speakers are under strain through excessive volume, excessive power, or by being used in a high temperature environment.	<ul style="list-style-type: none"> <li>• Switch off the unit, determine and correct the cause, then switch the unit on.</li> <li>• Use speakers with the right impedance rating.</li> </ul>	– 15–16
"F70" appears on the processor's display.		<ul style="list-style-type: none"> <li>• Turn off the power and then turn it on again, or disconnect the AC power supply cord and then connect it to your household AC outlet again.</li> </ul> (If "F70" still remains on the display, consult an authorized service center or your dealer.)	–

## Listening caution



Selecting fine audio equipment such as the unit you've just purchased is only the start of your musical enjoyment. Now it's time to consider how you can maximize the fun and excitement your equipment offers. This manufacturer and the Electronic Industries Association's Consumer Electronics Group want you to get the most out of your equipment by playing it at a safe level. One that lets the sound come through loud and clear without annoying blaring or distortion—and, most importantly, without affecting your sensitive hearing.

We recommend you to avoid prolonged exposure to excessive noise.

Sound can be deceiving. Over time your hearing "comfort level" adapts to higher volumes of sound. So what sounds "normal" can actually be loud and harmful to your hearing. Guard against this by setting your equipment at a safe level **BEFORE** your hearing adapts.

To establish a safe level:

- Start your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, and without distortion.

Once you have established a comfortable sound level:

- Set the dial and leave it there.

Taking a minute to do this now will help to prevent hearing damage or loss in the future. After all, we want you listening for a lifetime.

## Maintenance

### If the surfaces are dirty

To clean this unit, wipe with a soft, dry cloth.

If the surfaces are extremely dirty, use a soft cloth dipped in a soap-and-water solution or a weak detergent solution.

- Never use alcohol, paint thinner or benzene to clean this unit.
- Before using chemically treated cloth, read the instructions that came with the cloth carefully.

## Product service

Do not attempt to remove the cover(s) or repair the unit yourself. Refer servicing to qualified personnel only.

### Product information

For product service, product information or assistance with product operation, refer to the servicer directory.

Panasonic Consumer Electronics  
Company, Division of Matsushita  
Electric Corporation of America  
One Panasonic Way Secaucus,  
New Jersey 07094  
<http://www.panasonic.com>

Panasonic Sales Company,  
Division of Matsushita Electric of  
Puerto Rico, Inc. ("PSC")  
Ave. 65 de Infantería. Km. 9.5  
San Gabriel Industrial Park, Carolina,  
Puerto Rico 00985

Panasonic Canada Inc.  
5770 Ambler Drive,  
Mississauga, Ontario  
L4W 2T3  
[www.panasonic.ca](http://www.panasonic.ca)



RQT5110-P

H0499V0 (D)